



Cock Ring

User Manual



Specifications


Material	Silicone + ABS
Size	3.34*2.24*2.08in
Net Weight	54.9g
Waterproof	IPX6
Working Frequency	10 frequencies
Working Time	About 45 mins
Noise	<55db



Button Introduction

- Press the "⏻" button for 3s to turn on/off, press again to change the frequencies, 10 frequencies change cyclically.


2.08 in (53 mm)



Turn on/off Button
(Press for 3s to turn it on/off,
press again to change)

How to Charge

- Magnetic charging design;
- When the charging cable is attached to the 2 magnets on the product, the indicator light up, the button will flash, and the device will start charging.
- It takes 90 minutes to fully charge and can work continuously for 45 minutes. After fully charged, the indicator light stops flashing.



Magnetic charging hole

Cleaning and Maintain

- Clean the device with warm water and soap. And then run it through some hot water to wash any traces of soap.
- Pat it dry with a clean lint-free cloth or a microfiber towel so there is no fluff left on it.
- Put this product in a dry place, keep the storage environment clean and separate from other materials, and away from Children's contact range.
- Don't use alcohol to clean the product, for alcohol would corrode the surface of the product and accelerate its aging process.
- The product waterproof level is IPX6 and not suitable for playing in the water. For its long service life, don't soak it in the water for a long time.