

INYA

EROS RECHARGEABLE VIBE

For warranty information, latest products, and news visit us at:
nsnovelties.com

CARE

- * Turn off device when not in use.
- * Do not operate the device while charging.
- * Please follow the charge times indicated in the device specifications.
- * Wash after each use with liquid anti-bacterial soap and water.
- * Pat dry with a cotton towel and allow to air dry completely.

Product Dimensions: 4.37 x 1.57 x 3.27 (in),
Remote: 2.67 x 1.34 x 0.87 (in)
IPX Rating: Plug: IPX6, Remote: IPX3
Battery: Lithium Polymer
Charge Time: Do not exceed 120 minutes
Run Time: 50 minutes
Modes: 10




PLAY

- * Press & hold button on vibe for 2 seconds to power on/off.
- * Quick press button to cycle through modes.

PLAYING WITH REMOTE

- * To use the remote the device must be powered on.
- * Press & hold power button on remote for 2 seconds to power on/off.
- * Quick press +/- button(s) on the remote to cycle through modes.



CHARGE

- * The light will blink while the device is charging.
- * The light will become solid once the device is fully charged.

