

Product Specifications:

Category: Anal Plug Material: Silicone Size: W: 2.7", H: 4.75", D: 1.65" Battery: Lithium battery Voltage: 3.7V Number of Vibrations: 10 funtions of vibrations
User time: 1 hour
Sound Level: 55-60DB

CHARGING INSTRUCTIONS

MAKUND INSTITUTIONS
This vibrator arrives partially charged, so it is recommended to fully charge before use.

Connect the USB plug into the USB port of your computer or other output and the other end of the DC charger into toy's input. input.
Initial charge will take about 2 hours to complete, and

Initial charge will take about 2 hours to complete, and subsequent charges also take about 2 hours to complete. The Blue LED light will flosh while device is charging, and remain solid when toy is fully charged. There is no danger of battery damage by overcharging, but it's recommended not to overcharge for long periods of time. Charge lasts for about 60 minutes of play time for average use of varying speeds.

Toy vibration slows before stopping completely when charge is fully depleted.

This toy operates at a sound level of 55-60db and a power level of 3.7V.

INSTRUCTIONS FOR USE
This toy can be operated with or without the remote control. The toy has a 1-button control, and the remote control has a 2-button control.
Without the remote control:

Turn the toy on by pressing the Power Button at the base of the toy handle for at least 3 seconds.

Use the same Power Button to cycle through 10 speeds and functions of vibration.

Turn the toy off by pressing the Power Button for at least 3 seconds.

seconds.

seconds.
With the remote control:
Turn the toy on by pressing the Power Button on the remote for at least 3 seconds.
Use the Function Button to cycle through 10 speeds and

functions of vibration.

USB RECHARGEABLE



Turn the toy off by pressing the Power Button for at least 3 seconds.

You can start the toy directly with its Power Button, and then control it from the remote control are turning the remote on separately.

