

<http://www.genderx.com/>

**GENDER** X



**Product Specifications:**

Material: Silicone+ABS

Battery:

801921/ 280mAh

Voltage: 3.7v

Number of Vibrations: 9

User time: 1h

Sound Level: <45db

**CHARGING INSTRUCTIONS**

This vibrator arrives with high partial charge of about 70%, so the toy can be used immediately upon opening.

Connect the USB plug into the USB port of your computer or other output and the other end of the DC charger into toy's input, located below the toy's Power Button.

Initial and subsequent charges will take about an hour to complete.

The indicator light will flash on toy while device is charging and become solid when toy is fully charged. There is no danger of battery damage by overcharging, but it's recommended not to overcharge for long periods of time.

Charge lasts for about 90 minutes of play time on the lowest level of vibration, and about 60 minutes on the highest level.

This toy operates at a sound level of less than 45db with a 280mAh lithium battery at a voltage of 3.7V.

The remote control is operated by a CR2032 button battery, already installed.



**INSTRUCTIONS FOR USE**

This toy can be operated directly with the button at its base, or with the two buttons on its remote control. Important note: You cannot turn the toy ON or OFF with the remote control, but you can put it in standby mode. Use the button directly on the toy to power it on and off.

**OPERATE WITH TOY DIRECTLY**

Press the Power Button at toy's base for at least 3 seconds to turn toy on.

Press the Power Button again more quickly to cycle through 9 different vibration speeds and functions.

Once the toy is on, you may power on the remote and use its buttons to operate vibrations and functions separately.

To turn toy off, press Power Button for at least 3 seconds.

**OPERATE WITH REMOTE CONTROL**

Once the toy is on (by using the button at its base), press the Power Button on remote for at least 3 seconds to turn on the remote control.

Use the Function Button on remote to cycle through 9 different vibration speeds and functions.

Press the Power Button again for 3 seconds to turn off the remote control, which will put the toy in standby mode. The toy must be

turned off directly with its own button. However, after 20 minutes in standby mode, the toy will power off automatically by itself.