

Product Specifications:

Material: Silicone & ABS Plastic

Battery: 1000mAh

Voltage: 3.7V

Number of functions: Vibrating 2 Motors 10 functions each, Rotating Beads 10 functions

User time: 2 Hours Sound Level: 50 dB

CHARGING INSTRUCTIONS: This vibrator arrives with a very low partial charge, so it is

Connect the USB plug into the USB port of your computer or other output and the other end of the DC charger into toy's input, located at the back of the toy's base.

Initial charge will take about 1 hour and subsequent charges will take about 3 hours to

complete.
The indicator light will flash while device is charging and turn solid when toy is fully charged. There is no danger of battery damage by overcharging, but it's recommended not to overcharge for long periods of time.

Softime.

Charge lasts for 4 hours of play time using one function, 1.2 hours using 3 functions at their highest level, and about 1.9 hours using 3 functions on the lowest level of intensity. This toy operates at a sound level of 50db with a 1000mAh lithium battery at a voltage of 3.7V.

INSTRUCTIONS FOR USE: This toy has 3 motors operated with a 3-button control panel at the base of the toy's handle. The Bottom Button turns the toy on and controls vibration in the main shaft, the Left Button controls the twirling and bead functions in the main shaft (these two functions are controlled together), and the Right Button controls the vibration in the rabbit stimulator. Turn the toy on by pressing the Bottom Button for at least 3 seconds. The light will turn on and the toy will be in standby mode. Press the Bottom Button again to initiate the vibration in the main shaft which will begin at its lowest sneed and cycle through 10 speeds and functions.

lowest speed and cycle through 10 speeds and functions, including off.

including off.

Once the toy is turned on, press the Left Button to operate the twirling and bead rotation in the main shaft and cycle through 10 speeds and functions, including off. Twirling and bead rotation operate together.

Once the toy is turned on, press the Right Button to operate the vibration



the vibrating motor in the rabbit stimulator and cycle through 10 speeds and functions, including off. Turn toy off by pressing the Bottom Button for at least 3 seconds.