

PLAYBOY

Pleasure

Product Specifications:

Material: Silicone & ABS Plastic
Battery: Lithium battery
Voltage: 3.7V
Number of Vibrations: 10
User time: 40 - 60 minutes
Sound Level: <50db



CHARGING INSTRUCTIONS

This toy arrives with a partial charge of about 70%. It is not necessary to charge before first use.

To charge, connect the USB plug into a USB power source at one end, and the magnetic charging pins onto the magnetic port at the back of the toy's base.

Initial charge will take about 30 minutes and subsequent charges will take about 50 minutes to complete.

The indicator light will flash while device is charging and stay constant when toy is fully charged. There is no danger of battery damage by overcharging but it's recommended not to overcharge for long periods of time.

Charge lasts for about 40 minutes of play time on the highest level of vibration, and about 1 hour at the highest level.

This toy operates at a sound level of less than 50db with a rechargeable lithium battery at 3.7V.

INSTRUCTIONS FOR USE

This toy has a convenient 1-button control at the side of its base.

To turn toy on, press the button for at least 2 seconds. The light will turn on and toy will begin vibrating at its first lowest frequency. Press the button again more quickly to cycle through 10 speeds and functions.

To turn toy off, press button for at least 2 seconds.

VIBRATOR CARE INSTRUCTIONS

1. Compatible with Playboy Pleasure - Slick: H2O lubricant as well as other water-based lubricants. Make sure lubricants do not enter the battery compartment, as they may react with the batteries. Avoid use with silicone or oil-based lubricants as it will degrade the material over time.
2. Continuous constant use of the vibrator's motor may create excessive heat. If your vibrator feels too hot, switch it off and allow it to cool before continuing use. Avoid prolonged exposure to sunlight and extreme heat.
3. Clean your vibrator after every use with Playboy Pleasure - Clean; Foaming Toy Cleaner and a warm water rinse. Dry thoroughly before storage.
4. Store your vibrator in a cool, dry place separated from other toys, as toy materials sometimes react chemically with each other.

