

# PLAYBOY

## *Pleasure*

### Product Specifications:

Material: Silicone & ABS Plastic  
Battery: Li-ion Battery 751524 3.7V 220mAh 0.814Wh 4.4g  
Voltage: 3.7V  
Number of Vibrations: 7  
User time: 40 - 80 minutes  
Sound Level: ≤60Db



### CHARGING INSTRUCTIONS

This toy arrives with a partial charge of about 30%. It is recommended to use up this energy before recharging for the first time. Repeat this charging cycle 3 times to maximize battery life.

To charge, connect the USB plug into a USB power source at one end, and the DC charger plug into the port at the back of the toy's base.

Initial and subsequent charges will take about 1 hour to complete.

The indicator light will flash while device is charging and stay constant when toy is fully charged. There is no danger of battery damage by overcharging but it's recommended not to overcharge for long periods of time.

Charge lasts for about 1 hours of play time on the highest level of vibration.

This toy operates at a sound level of less than 60db with a rechargeable 220mAh lithium battery at 3.7V.

### INSTRUCTIONS FOR USE

This toy has a convenient 1-button control at its base that operates both motors simultaneously.

To turn toy on, press the button for at least 2 seconds. The light will turn on and toy will begin vibrating at its first lowest frequency. Press the button again more quickly to cycle through 7 speeds and functions.

To turn toy off, press button for at least 2 seconds.

### VIBRATOR CARE INSTRUCTIONS

1. Compatible with Playboy Pleasure - Slick: H2O lubricant as well as other water-based lubricants. Make sure lubricants do not enter the battery compartment, as they may react with the batteries. Avoid use with silicone or oil-based lubricants as it will degrade the material overtime.
2. Continuous constant use of the vibrator's motor may create excessive heat. If your vibrator feels too hot, switch it off and allow it to cool before continuing use. Avoid prolonged exposure to sunlight and extreme heat.
3. Clean your vibrator after every use with Playboy Pleasure - Clean: Foaming Toy Cleaner and a warm water rinse. Dry thoroughly before storage.
4. Store your vibrator in a cool, dry place separated from other toys, as toy materials sometimes react chemically with each other.

CONTAINS BATTERY  
AND MUST BE RECYCLED



Li-ion