


zerotolerancetoys.com

ZERO TOLERANCE



Product Specifications:

Material: TPR & ABS

Battery: 902040 650Ah

Voltage: 3.7V

Number of functions: 5

User time: 90 Minutes

Sound level: <55dB

CHARGING INSTRUCTIONS

It is recommended to fully charge this toy before use.

Connect the USB plug into a power source and the other end of the DC charger onto the magnetic charging pins below the 1-button control panel at the front of the toy.

Initial and subsequent charges will take about 2 hours to complete.

The indicator light will flash on toy while device is charging and become solid when toy is fully charged. There is no danger of battery damage by overcharging, but it's recommended not to overcharge for long periods of time.

Charge lasts for about 90 minutes of play time on average.

This toy operates at a sound level of less than 55db with a 650mAh lithium battery at a voltage of 3.7V.

The remote control uses 1 AAA battery, not included.

INSTRUCTIONS FOR USE

This toy can be operated directly with the button on the front of the toy, or with the three buttons on its remote control.

Important note: You cannot turn the toy ON or OFF with the remote control. Use the button directly on the toy to power it on.

OPERATE WITH TOY DIRECTLY

Press the single button at the front of the toy for at least 3 seconds to turn toy on. The light will illuminate and both motors will be in standby mode. Press the button again more quickly to cycle through 5 different vibration and sucking speeds and patterns in both motors at once, including off. To turn toy off, press button for at least 3 seconds.

Once the toy is on, you may power on the remote and use its buttons to operate vibrations and sucking functions separately.

OPERATE WITH REMOTE CONTROL

Once the toy is on (by using the button on toy directly), press the top Mouth (Power / Sucking) Button on the remote for at least 2 seconds to turn it on. Press this button again more quickly to

engage the suction function in the inner channels. Press again to cycle through 5 sucking patterns in all, as well as standby.

Once toy and remote have been turned on, press the bottom Vibration

Button on remote for at least 2 seconds to engage the vibration in the inner channels. Press again more quickly to cycle through 5 different vibration speeds and patterns, as well as standby.

Use the middle button for a quick release of the suction function. Press once and suction will immediately release and stop.

Press the top Mouth Power Button again for 2 seconds to turn the remote off and put the toy in standby mode (no matter what speed it's on).

CLEANING INSTRUCTIONS

There are two air intake holes at the top smooth surface of this toy that are used to facilitate drainage and pressure release in the inner channels. Attention: Do not block these intake holes.

Fill the included 12-oz bottle with water and aim it into the vaginal channel. Make sure the intake holes are pointed at the sink or somewhere to drain the water into. Turn on the suction motor as indicated in the usage instructions and squeeze the bottle until all the water is gone, letting it drain out from the two air intake holes at the top surface of the toy.

