

<http://www.genderx.com/>

GENDER X



Product Specifications:

Material: Silicone & ABS
Battery: 601230 190mAh
Voltage: 3.7V
Number of Vibrations: 12
User time: 45 - 60 Minutes
Sound Level: <55dB

CHARGING INSTRUCTIONS

It is recommended to charge the toy fully before first use. To charge, connect the USB plug to a power source and place the other end into the charging port at the back of the ringed handle. The indicator light will flash while device is charging and stay constant when toy is fully charged. Initial charge will take about an hour; subsequent charges 90 minutes. Charge lasts for about one hour using the lowest level of vibration and about 45 minutes with the highest. This toy operates at a sound level of

less than 55db with a rechargeable 190mAh lithium battery at 3.7V.



INSTRUCTIONS FOR USE

1. The toy's 2-button control panel is located at the front of the ringed handle.
2. Use the Power Button to turn the toy on by pressing for at least 2 seconds. The button will light up and the motor will begin in standby.
3. Press the vibration button to cycle through 12 vibration speeds and patterns of vibration.
4. Press the Power Button for at least 2 seconds to turn the toy off.